

# ROTISSERIE INSTALLATION INSTRUCTIONS

## PARTS INCLUDED:

- 1 ROTISSERIE ROD
- 1 ROTISSERIE ROD BUSHING / WITH SET SCREW  
(Attached)
- 2 ROTISSERIE ROD FORKS / W SET SCREWS
- 1 COUNTER BALANCE / W SET SCREW
- 1 ROTISSERIE MOTOR MOUNTING BRACKET
- 1 ROTISSERIE MOTOR
- 2 #10-32 STAINLESS STEEL BOLTS, NUTS AND LOCK WASHERS



Attach the Rotisserie Mounting Bracket to the Inner Hood using the Two (2) #10-32 Stainless Steel bolts Nuts and Lock washers supplied.

Slide the motor over the mounting bracket.

Install the counter balance by sliding the clamping ring over the rod and threading the counter balance shaft into the ring until tight, adjust the counter balance weight by tightening the set screw in the desired location.

Slide the forks over the rod and tighten set screw in the desired location.

Install the rod into the already installed motor and place the Rotisserie Rod bushing in the notch on the right hand side of the Inner Hood.

